

Purpose

To show the process of a replacing a canister.

Scope

Archimede A2XX & A3XX dispensers.

Safety

Follow all standard safety practices when working on any equipment.

Tools and materials required

• A pair of pliers may be required depending upon tightness of wingnut.

1 Removal		
Step	Instruction	Image
1.1	Lift open the main lid of the dispenser.	
1.2	Remove the can shelf.	



Archimede A2XX & A3XX Canister Replacement INST-00123

1.3	Locate the dispense tube corresponding to the canister you are replacing and remove the nozzle by pulling it straight up.	
1.4	Rotate the carousel so that the canister you want to replace is facing you.	
1.5	Disconnect the dispense tube from the clips that hold it to the unit.	



Archimede A2XX & A3XX Canister Replacement INST-00123

1.6	Remove the plug from the agitation lid and detach the wire from the backside of the canister.	
1.7	Open the front access door or panel. Some units will require a key which when unlocked allows the door to open. Other units require removal of a screw, when removed the panel can be lifted up to open. (Shown)	
1.8	Locate the motor which is attached below the canister and unplug the electrical connector shown. Note: If the canister is a center canister you may need to remove an outer canister to more easily get to this.	



1.9	Locate the wingnut that sits in front of the motor and directly below the canister. Remove this, if required use pliers. Note: If the canister is a center canister you may need to remove an outer canister to more easily get to this.	
1.10	Carefully lift the canister out of the dispenser.	

2 Installation

Step	Instruction	Image
2.1	Reverse previous steps.	
2.2	If the colorant in the old canister is still good you may use it to fill the new canister. Otherwise, use fresh colorant.	
2.3	Dispense 10Y (10oz) of colorant from the new canister. Watch it dispense and make sure no air pockets are visible or audible.	
	If required dispense another 10Y.	